SOW CHANGE PROPOSAL

SOW-04-CBG-ROCFMS-1/1	Change 2	01/13/2004
SOW-05-PMM143-ROCFMS-1/1	Change 2	01/13/2004

STATEMENT OF WORK (SOW)
for the
Execution of the
Republic Of China Marine Corps
Foreign Military Sale of Assault Amphibious Vehice
(AAV)
Reliability, Availability, Maintainability
(RAM)
(AAV7A1 RAM)
Family of Vehicles
(FOV)

On page 17 of the original SOW's remove "Appendix G: GFM/GFE REPAIR Worksheet" and replace with "GFE/GFM REPAIR WORKSHEET".
(This worksheet is part of Appendix E, Appendix G)
If approved, does this proposed change have the potential to have an impact on the cost or schedule?
* Yes /_/ or No /X/ (Place and X in the appropriate block)

*Changes that have the potential to impact cost or schedule will be reviewed by Maintenance Directorate (MD) and an impact statement provided to LCMC. Changes that do not have the potential to impact cost or schedule may not be reviewed by MD.

Change Submitted by: _R. E. Hoffman_____ (Name) 01/13/2004 Date
Equipment Specialist_____(Title)
AAVS_____ (Code PMM143)
MARCORSYSCOM, Albany GA

Change Approved by R. E. Hoffman_____ (Name) 01/13/2004 Date
Logistics Management Specialist(Acting)
AAVS_____ (CodePMM143)
MARCORSYSCOM, Albany, GA

Change Disapproved by _____ (Name) _____Date
Logistics Management Specialist
_____ (Code _____)
MARCORSYSCOM, Albany, GA

Appendix G: Parts Removed with Disposition Instructions

Disassembled Item	Consisting of	NSN/PN	Qty	Major Assembly	Disposition
Engine		2815-01-109-5052	54	power plant	Remove and hold in project PFN
Transmission		2520-01-390-3750	54	power plant	Remove and hold in project PFN
Transmission	HSU	2530-01-125-0461	54	power plant	Remove and hold in project PFN
Transmission	PTO	2990-00-225-3220	54	power plant	Remove and hold in project PFN
Cooling Fan Assembly		4140-00-450-1974	44	power plant	Remove and hold in project PFN
Torque Converter		2520-01-113-6131	54	power plant	Remove and hold in project PFN
Valve body (range)		4810-00-205-4132	54	power plant	Remove and hold in project PFN
Turbo Assembly		2810-01-135-7475	54	power plant	Remove and hold in project PFN
Fuel pump (P/C)		2910-01-141-8618	54	power plant	Remove and hold in project PFN
Stater		2920-01-151-3762	54	power plant	Remove and hold in project PFN
Generator		2920-01-134-8842	44	power plant	Remove and hold in project PFN
Oil cooler		2930-01-141-4330	54	power plant	Remove and hold in project PFN
Harness, Fwd port (1W11)		5995-01-165-5659	54	power plant	Remove and hold in project PFN
Engine Harness		5995-01-112-7019	54	power plant	Remove and hold in project PFN
Transmission Harness		5995-01-112-7018	54	power plant	Remove and hold in project PFN
Heat Exchanger		D281060	54	power plant	Remove and hold in project PFN
Radiator (new style)		2930-01-418-6462	54	power plant	Remove and hold in project PFN
Cooling System		2600095	54	power plant	Remove and hold in project PFN
Reservoir Assembly		2600491	54	power plant	Remove and hold in project PFN
Fuel filter separator		4930-00-477-8276	54	power plant	Remove and hold in project PFN
Muffler		2990-01-113-9321	54	power plant	Remove and hold in project PFN
UGWS	numerous parts - below	None	48	Turret	Remove and hold in project PFN
UGWS	Slip Ring, 12 Channel	1010-01-258-9638	48	Turret	Remove and hold in project PFN
UGWS	Relay Power Unit	1010-01-258-9660	48	Turret	Remove and hold in project PFN
UGWS	Wiring Harness	6150-01-111-4990	48	Turret	Remove and hold in project

	(4W10)				PFN
UGWS	Wiring Harness (1W9)	6150-01-114-4760	48	Turret	Remove and hold in project PFN
UGWS	Wiring Harness (4W102)	5995-01-449-3110	48	Turret	Remove and hold in project PFN
UGWS	Wiring Harness (W5)	5995-01-258-9598	48	Turret	Remove and hold in project PFN
UGWS	Wiring Harness (W3, W1)	6150-01-389-6169	48	Turret	Remove and hold in project PFN
UGWS	Wiring Harness (W4)	6150-01-284-4003	48	Turret	Remove and hold in project PFN
UGWS	Wiring Harness (W2)	6150-01-285-9719	48	Turret	Remove and hold in project PFN
UGWS	Weapons Control Box	1010-01-257-9961	48	Turret	Remove and hold in project PFN
UGWS	Turret Power Box	1010-01-257-9962	48	Turret	Remove and hold in project PFN
UGWS	Switch, Traverse Box	5930-01-258-9659	48	Turret	Remove and hold in project PFN
UGWS	Elevation Control Assembly	1010-01-258-1473	48	Turret	Remove and hold in project PFN
UGWS	Traverse Mechanism Assembly	1010-01-258-9661	48	Turret	Remove and hold in project PFN
Entire turret		1010-01-233-9493	48	Turret	Remove and hold in project PFN
Sprocket Wheel		3020-01-126-3940	108	suspension	Remove and hold in project PFN
Shocks		2540-01-158-1125	324	suspension	Remove and hold in project PFN
Idler Assembly		2530-00-438-5138	108	suspension	Remove and hold in project PFN
Support Assembly (Right)		2530-00-438-5150	324	suspension	Remove and hold in project PFN
Support Assembly (Left)		2530-00-438-5156	324	suspension	Remove and hold in project PFN
Piston, Track Adjuster		2530-01-107-3764	108	suspension	Remove and hold in project PFN
Final Drives		2520-01-125-5933	108	suspension	Remove and hold in project PFN
Roadwheels		2530-00-424-3789	1296	suspension	Remove and hold in project PFN
Idler/track adjuster bracket		2990-01-107-1294	54	suspension	Remove and hold in project PFN
Slap guard		2540-01-108-7789	54	suspension	Remove and hold in project PFN
Fire Bottle, Fwd Engine		4210-01-331-6714	54	hull	Remove and hold in project PFN
Fire Bottle, Aft Engine		4210-01-331-6714	54	hull	Remove and hold in project PFN
Fire Bottle, Troop Compt		4210-00-435-9415	54	hull	Remove and hold in project PFN
Fire Bottle, Fwd Troop		4210-01-321-6527	54	hull	Remove and hold in project

					PFN
Fire Bottle, Aft Troop		4210-01-321-6527	54	hull	Remove and hold in project PFN
Electric Bilge Pumps		4320-01-111-0813	108	hull	Remove and hold in project PFN
Hydraulic Bilge Pumps		4320-01-111-6807	108	hull	Remove and hold in project PFN
Bow Plane		2510-01-320-3771	52	hull	Remove and hold in project PFN
Bow Plane Actuator		3010-01-320-8359	52	hull	Remove and hold in project PFN
DDU		2350-01-199-6319	54	hull	Remove and hold in project PFN
Right Angle Drives		2520-00-428-0971	108	hull	Remove and hold in project PFN
Ramp Cylinder		3040-00-432-4876	54	hull	Remove and hold in project PFN
Engine Panel		2600226	54	hull	Remove and hold in project PFN
Engine Panel		2600227	54	hull	Remove and hold in project PFN
Engine Panel		2600469	54	hull	Remove and hold in project PFN
Engine Panel		2600684	54	hull	Remove and hold in project PFN
Hydro Steer Bracket, Right		2587958-2	54	hull	Remove and hold in project PFN
Hydro Steer Bracket, Left		2587958-1	54	hull	Remove and hold in project PFN
Driver's/TC Seat		2623066	108	hull	Remove and hold in project PFN
Bench Seats (Port)		2585610	48	hull	Remove and hold in project PFN
Bench Seats (Strb)		2600843	48	hull	Remove and hold in project PFN
Bench (Center, Fwd)		2589659	48	hull	Remove and hold in project PFN
Bench (Center, Aft)		2585066	48	hull	Remove and hold in project PFN
Inst Distribution box		2600143	48	hull	Remove and hold in project PFN
Power Distribution Box		5429046	48	hull	Remove and hold in project PFN
Cold start resistor assembly		2600637	48	hull	Remove and hold in project PFN
Vent fan crew		4140-01-113-8312	48	hull	Remove and hold in project PFN
Exhaust fan		4140-01-113-8313	48	hull	Remove and hold in project PFN
Battery box cover		5428978	48	hull	Remove and hold in project PFN
Cover (footbal bow)		2587751	48	hull	Remove and hold in project PFN
Headlight (stbd)		6220-01-225-3616	48	hull	Remove and hold in project

					PFN
Headlight (port)		6220-01-111-5235	48	hull	Remove and hold in project PFN
Water jet deflector control assembly	numerous parts - below	None		hull	Remove and hold in project PFN
Water jet deflector control assembly	steering wheel position detector	2530-00-432-1787	48	hull	Remove and hold in project PFN
Water jet deflector control assembly	sensing module	2590-00-431-9120	48	hull	Remove and hold in project PFN
Water jet deflector control assembly	water-jet deflector servo module	6110-00-270-0340	96	hull	Remove and hold in project PFN
Water jet deflector control assembly	water-jet deflector solenoid	4810-01-222-4617	96	hull	Remove and hold in project PFN
Water jet deflector control assembly	steering wheel	2530-01-037-4844	48	hull	Remove and hold in project PFN
Water jet deflector control assembly	plate	2588917	48	hull	Remove and hold in project PFN
Water jet deflector control assembly	clevis, rod end	5340-00-158-3990	48	hull	Remove and hold in project PFN
Water jet deflector control assembly	bellcrank	3040-00-497-6680	48	hull	Remove and hold in project PFN
Water jet deflector control assembly	actuator cylinder	3040-00-722-5123	48	hull	Remove and hold in project PFN
Water jet deflector control assembly	water-jet deflector	2623004-1	48	hull	Remove and hold in project PFN
Water jet deflector control assembly	reverse flow duct	2835-01-107-7453	48	hull	Remove and hold in project PFN
Propulsion unit		2010-01-107-7454	48	hull	Remove and hold in project PFN
Fuel cell		2910-01-131-8949	48	hull	Remove and hold in project PFN
Vehicle wiring harnesses	numerous parts - below	None		hull	Remove and hold in project PFN
Vehicle wiring harnesses	Wiring harness (1W1)	2590-01-159-2956	54	hull	Remove and hold in project PFN
Vehicle wiring harnesses	Wiring harness (1W7)	2600900	54	hull	Remove and hold in project PFN
Vehicle wiring harnesses	Wiring harness (1W8)	5995-01-108-7064	54	hull	Remove and hold in project PFN
Vehicle wiring harnesses	Wiring harness (1W10)	5995-01-165-5658	54	hull	Remove and hold in project PFN
Vehicle wiring harnesses	Wiring harness (1W11)	5995-01-165-5659	54	hull	Remove and hold in project PFN
Vehicle wiring harnesses	Wiring harness (1W12)	5995-01-235-6879	54	hull	Remove and hold in project PFN
Vehicle wiring harnesses	Wiring harness (1W14)	5995-01-165-5661	54	hull	Remove and hold in project PFN
Deck plate port		2601064	48	hull	Remove and hold in project PFN
Deck plate center		2600410	48	hull	Remove and hold in project PFN

Deck plate stbd		2601065	48	hull	Remove and hold in project PFN
Anode		2586540	48	hull	Remove and hold in project PFN
Air Box Assembly		2940-01-114-0171	48	hull	Remove and hold in project PFN
Heater Assembly		2540-01-262-6013	48	hull	Remove and hold in project PFN
Water can bracket		5439049	48	hull	Remove and hold in project PFN
Tool Box bracket		2600561	48	hull	Remove and hold in project PFN
Ramp lock linkage and handle	numerous parts - below	None		hull	Remove and hold in project PFN
Ramp lock linkage and handle	Handle, ramp lock	2584532	54	hull	Remove and hold in project PFN
Ramp lock linkage and handle	Pawl	3040-00-040-1079	54	hull	Remove and hold in project PFN
Ramp lock linkage and handle	Clevis, rod	5340-00-158-0295	108	hull	Remove and hold in project PFN
Ramp lock linkage and handle	Rod, threaded	5306-01-107-3675	54	hull	Remove and hold in project PFN
Ramp lock linkage and handle	Hook, locking ramp	2040-01-107-4258	108	hull	Remove and hold in project PFN
Ramp lock linkage and handle	Spring, helical	5360-00-158-0302	108	hull	Remove and hold in project PFN
Ramp lock linkage and handle	Pin, grooved	5315-00-936-7125	108	hull	Remove and hold in project PFN
Ramp lock linkage and handle	Clevis, rod	5340-00-158-0295	108	hull	Remove and hold in project PFN
Ramp lock linkage and handle	Connecting link	3040-01-108-0825	108	hull	Remove and hold in project PFN
Ramp lock linkage and handle	Bushing, rubber	5365-00-050-1580	432	hull	Remove and hold in project PFN
Ramp lock linkage and handle	Rod, threaded	5306-01-107-2855	108	hull	Remove and hold in project PFN
Ramp lock linkage and handle	Washer, flat	5310-00-080-6004	216	hull	Remove and hold in project PFN
Ramp lock linkage and handle	Base, catch	2586110	108	hull	Remove and hold in project PFN
Ramp lock linkage and handle	Cap, pillow block	3130-00-158-2466	162	hull	Remove and hold in project PFN
Ramp lock linkage and handle	Washer, flat	5310-00-408-6123	AR	hull	Remove and hold in project PFN
Ramp lock linkage and handle	Actuator, latch	2040-01-107-3765	54	hull	Remove and hold in project PFN
AFSSS system	numerous parts - below	None		hull	Remove and hold in project PFN
AFSSS system	Wiring harness, valves	5433326	54	hull	Remove and hold in project PFN
AFSSS system	Wiring harness, sensors	5433328	54	hull	Remove and hold in project PFN
AFSSS system	Wire	6145-01-081-8994	AR	hull	Remove and hold in project PFN

AFSSS system	Wire	6145-00-177-4607	AR	hull	Remove and hold in project PFN
AFSSS system	Connector (P10)	2618688-19	54	hull	Remove and hold in project PFN
AFSSS system	Connector (P3)	5935-01-115-0215	162	hull	Remove and hold in project PFN
AFSSS system	Connector (P1)	2618688-20	54	hull	Remove and hold in project PFN
AFSSS system	Wire	6145-01-120-5623	AR	hull	Remove and hold in project PFN
AFSSS system	Wire	6145-01-112-1815	AR	hull	Remove and hold in project PFN
AFSSS system	Connector P8 P7 P6	2618688-18	216	hull	Remove and hold in project PFN
AFSSS system	Connector	5935-01-135-3564	54	hull	Remove and hold in project PFN
Tow pintle		2540-01-193-2117	48	hull	Remove and hold in project PFN
Radio guard		2586996	48	hull	Remove and hold in project PFN
Reverse flow duct		2835-01-107-7453	48	hull	Remove and hold in project PFN
Longitudinal drive shaft		2530-01-075-2669	48	hull	Remove and hold in project PFN
Lateral Drive shaft		2520-00-451-9649	48	hull	Remove and hold in project PFN
Seat (Port)		2618104	4	C7 unique	Remove and hold in project PFN
Seat (Strb)		2611811	4	C7 unique	Remove and hold in project PFN
Harness (1W109)		6150-01-449-5467	4	C7 unique	Remove and hold in project PFN
Harness (1W129)		5995-01-449-4514	4	C7 unique	Remove and hold in project PFN
Harness (1W121)		5995-01-449-4502	4	C7 unique	Remove and hold in project PFN
Harness (1W103)		5995-01-449-4562	4	C7 unique	Remove and hold in project PFN
Harness (1W116)		5995-01-449-5454	4	C7 unique	Remove and hold in project PFN
Fuel Pump (R)		2910-01-166-8379	2	R7 unique	Remove and hold in project PEX
AC Dist Box Assembly		6110-01-172-2104	2	R7 unique	Remove and hold in project PEX
Boom Assembly		5433217	2	R7 unique	Remove and hold in project PEX
Boom Base Assembly		5433219	2	R7 unique	Remove and hold in project PEX
Winch Assembly		2590-01-245-7170	2	R7 unique	Remove and hold in project PEX
Air Compressor		4310-00-008-6079	2	R7 unique	Remove and hold in project PEX
Air Tank		2624997	2	R7 unique	Remove and hold in project PEX

AC Motor		6105-01-364-1717	2	R7 unique	Remove and hold in project PEX
Welder		7003014	2	R7 unique	Remove and hold in project PEX
Kato Generator		2617247	2	R7 unique	Remove and hold in project PEX
Magnetic Clutch Drive Assy		3010-01-228-1165	2	R7 unique	Remove and hold in project PEX
Governor Control Link Assy		None	2	R7 unique	Remove and hold in project PEX
Governor Control Link Assy	bushing	3120-01-174-0588	2	R7 unique	Remove and hold in project PEX
Governor Control Link Assy	spring	5360-01-167-2576	2	R7 unique	Remove and hold in project PEX
Governor Control Link Assy	pin	5315-01-171-6713	2	R7 unique	Remove and hold in project PEX
Governor Control Link Assy	nut	5310-00-975-2075	2	R7 unique	Remove and hold in project PEX
Governor Control Link Assy	cylinder	2530-01-164-2398	2	R7 unique	Remove and hold in project PEX
Governor Control Link Assy	pin	5315-00-839-2325	2	R7 unique	Remove and hold in project PEX
Governor Control Link Assy	washer	5310-00-081-4219	2	R7 unique	Remove and hold in project PEX
Governor Control Link Assy	bushing	3120-01-174-0588	2	R7 unique	Remove and hold in project PEX
Governor Control Link Assy	link	3040-01-166-1357	2	R7 unique	Remove and hold in project PEX